

## Documentation:

### Remote Kit for SDC with PC-Software



1. create a new folder with name „SDC“. Copy all Files of the CD into this folder.
2. Put the USB-Transceiver Stick in the USB Board of your PC. Install the Driver with double click on CP210x\_VCP\_Win2K\_XP\_Vista.exe. Reboot the PC.
3. Connect the other Transceiver to the PC/CP Slot at your SDC



4. Open the Interface with doubleclick on SDC.exe. Now select „E-Drive“ then „Online Drive“ Choose your com port you installed before. Connect your battery to the SDC. Press Start communication.
5. When you have enabled your drive with the green button, press the button again for 2 seconds. Now your PC-Interface is the master for controlling the drive speed. You see it in the control information „remote control“.

**Attention: Note that you can only deactivate your drive with the Stop Button on the PC or press short the green button at the interface!**

